

ŠIAULIAI INTL/CIV/MIL - EYSA

1. Koordinatės ir padėtis

55 53 38N 023 23 42E

6.5 km atstumu į pietryčius nuo Šiaulių miesto centro.

2. Adresas

Oro uostas

Lakūnų g. 4

77103 Šiauliai

Tel. (8 41) 54 20 05

Faks. (8 41) 54 20 06

AFS: EYSAYDYX

El. paštas: ops.airport@siauliai.lt

3. Paskirtis

Skrydžiai pagal IFR ir VFR.

4. Darbo valandos

AD administracija:

kasdien 0600 – 1445 (0500 – 1345).

Pagal užklausą:

1445 – 0600 (1345 – 0500)¹

Aerodromo OPR HR: H24^{2,3}.

ATS OPR HR: H24.

Pastabos:

1. Visiems civilinės aviacijos skrydžiams papildomą informaciją dėl skrydžių į Šiaulių oro uostą teikia oro uosto administracija Mob.: 8 655 93 147; 8 699 87 300; 8 682 21 943; 8 650 26 040.
2. Visi civilinių ir karinių orlaivių skrydžiai leidžiami tik gavus Aviacijos bazės administracijos leidimą. Prašymai (PPR) atskristi į Šiaulių aerodromą pateikiami ne vėliau kaip 24 valandas prieš planuojamą skrydį. Telefonas pasiteirauti (8 41) 42 06 13 (taip pat žr. AIC A003/2013).
3. Orlaiviams, planuojantiems atskristi/išskristi nuo 2100 iki 0600 (2000-0500) bus taikomi viršreglamentiniai darbo laiko tarifai. Užklausimą oro uosto administracijai privalu pateikti ne vėliau kaip prieš 6-ias valandas iki planuojamo skrydžio.

5. Muitinė/Imigracija

H24

1. Coordinates and location

55 53 38N 023 23 42E

6.5 km SE from Šiauliai

2. Address

Airport

Lakūnų g. 4

LT-77103 Šiauliai

Tel. +370 41 54 20 05

Fax +370 41 54 20 06

AFS: EYSAYDYX

E-mail: ops.airport@siauliai.lt

3. Approved for

IFR and VFR flights.

4. Operational hours

AD administration:

Daily 0600 – 1445 (0500 – 1345).

On request:

1445 – 0600 (1345 – 0500)¹

Aerodrome OPR HR: H24^{2,3}.

ATS OPR HR: H24.

Remarks:

1. Additional information for all civil flights to Šiauliai AD Administration by Mob.: +370 655 93 147; +370 699 87 300; +370 682 21 943; +370 650 26 040.
2. Permits for all civil and military flights shall be obtained from the Administration of Air Base. Prior permission request (PPR) to Šiauliai AD shall be submitted not later than 24 HRs before the planned flight. Contact Tel. +370 41 42 06 13 (also see AIC A003/2013).
3. For the aircraft, which are planning to arrive/depart from 2100 till 0600 (2000-0500), an overtime tariff will be applied. The airport administration shall be informed no later than 6 HRs before the intended flight.

5. Customs/Immigration

H24

6. Degalai, tepalai ir priemonės nuo apledėjimo

Degalai: Jet A1

Tepalai: nėra

Degalų pylimas:

Kasdien 0600-2100 (0500-2000)

Pagal užklausą: 2100-0600 (2000-0500)

Priemonės nuo apledėjimo: yra

Darbo valandos: kasdien 0600-2100 (0500-2000)

Pagal užklausą: 2100-0600 (2000-0500)

7. Angarai atskrendantiems orlaiviams

Nėra

8. Taisymo įranga atskrendantiems orlaiviams

Nėra

9. Gelbėjimo ir priešgaisrinė tarnyba

Priešgaisrinė tarnyba: pagal AD darbo laiką.

Priešgaisrinės įrangos kategorija: CAT 7.

Gelbėjimo įranga: yra.

Įvykus avarijai aerodromo teritorijoje, gelbėjimo darbus atlieka aerodromo administracija, pasitelkusi aplink esančias paieškos ir gelbėjimo struktūras. Apie įvykį pranešti:

a) priešgaisrinei tarnybai

Tel.: (8 41) 54 20 01 arba 112

b) Aeronautikos gelbėjimo

koordinaciniam centrui

Tel.: (8 5) 219 4587

(8 5) 219 4588

(8 5) 219 4585

Mob. 8 610 4 60 24

c) Civilinės aviacijos administracijai

Tel.: (8 5) 273 92 59

(8 5) 273 92 60

Mob. 8 698 8 59 45

10. Sezoninis tinkamumas

Sniego valymo įranga: yra

11. Viešbučiai

Mieste, pagal užsakymą oro uoste.

12. Restoranas

Oro uoste ir mieste.

13. Turizmo biuras

Mieste

6. Fuel, Oil and De-icing Fluid, etc.

Fuel: Jet A1

Oil: NIL

Fuelling:

Daily 0600-2100 (0500-2000)

On request: 2100-0600 (2000-0500)

De-icing fluid: Available

Operational hours: daily 0600-2100 (0500-2000)

On request: 2100-0600 (2000-0500)

7. Hangar Space for Visitors

NIL

8. Repair Facilities Available

NIL

9. Rescue and Fire Fighting Service

Fire fighting service: within AD HR.

Category for fire fighting equipment: CAT 7

Rescue equipment: Available.

In emergency on the territory of aerodrome rescue and fire fighting service is provided by appropriate neighbouring authorities. An incident should be reported to:

a) Fire fighting service

Tel.: +370 41 54 20 01 or 112

b) Aeronautical Rescue Coordination

Centre

Tel.: +370 5 219 4587

+370 5 219 4588

+370 5 219 4585

Mob. +370 610 4 60 24

c) Civil Aviation Administration

Tel.: +370 5 273 92 59

+370 5 273 92 60

Mob. +370 698 8 59 45

10. Seasonal Availability

Snow clearing equipment: Available

11. Hotels

In the city, on request at airport.

12. Restaurant

At airport and in the city.

13. Tourist Office

In the city

14. Medicinos įstaigos

Pirmoji pagalba AD. Ligoninės mieste.

15. Transportas

Autobusai, taksi pagal užsakymą.

Automobilių nuoma AD.

16. Pastabos

a. Išskrendantys orlaiviai pradeda ryšį su TWR, kad gautų ATC leidimą dar prieš pradėdami riedėti. Naudojamasi 120.400 MHz dažniu. Išskrendantys orlaiviai 120.400 MHz dažniu iš TWR gauna leidimą stumti ir riedėti.

b. Mokomieji, pratybų bei techninių bandymų skrydžiai galimi tik Šiaulių TWR leidimu.

c. Kilimo ir tūpimo tako klasifikacija:

<u>KTT Nr.</u>	<u>KTT kodas</u>	<u>Danga</u>
14L	4E	Asfaltbetonis
32R	4E	Asfaltbetonis

14. Medical Facilities

First Aid at AD. Hospitals in the city.

15. Transport

Buses, taxis on request.

Rent a car service at AD.

16. Remarks

a. Departing aircraft contact TWR to obtain ATC clearance before taxiing. Frequency 120.400 MHz is to be used. Departing aircraft shall obtain the push-back and taxi clearance from TWR on 120.400 MHz.

b. School- and training, technical test flights can only be made after permission there to has been obtained from Šiauliai TWR.

c. RWY classification:

<u>RWY Nr.</u>	<u>RWY code</u>	<u>Surface</u>
14L	4E	Asphalt-Concrete
32R	4E	Asphalt-Concrete

AERODROME GROUND MOVEMENT
AND PARKING CHART

ŠIAULIAI / INTL / CIV / MIL

AD ELEV: 445
ARP: 55 53 38N 023 23 42E



ŠIAULIAI TOWER : 120.400


ATIS 120.750

FIS : ŠIAULIAI INFORMATION 124.450

Not to scale

Datum : WGS-84

ELEV IN FT



Not to scale

COORDINATES (WGS-84) & STRENGTH
FOR AIRCRAFT STANDS

1 - 55 54 13.40N 023 21 45.60E	PCN 32 / R / B / X / T	19 - 55 53 43.09N 023 23 09.98E	PCN 32 / R / C / W / T
2 - 55 54 14.00N 023 21 45.00E	PCN 32 / R / B / X / T	20 - 55 53 46.21N 023 23 01.14E	PCN 60 / R / B / W / T
3 - 55 54 14.50N 023 21 46.50E	PCN 32 / R / B / X / T	21 - 55 53 46.59N 023 23 00.69E	PCN 60 / R / B / W / T
4 - 55 54 09.70N 023 22 36.20E	PCN 32 / R / B / X / T	22 - 55 53 47.70N 023 22 59.37E	PCN 60 / R / B / W / T
5 - 55 54 30.09N 023 23 10.34E	PCN 85 / R / C / W / T	23 - 55 53 48.91N 023 22 58.03E	PCN 60 / R / B / W / T
6 - 55 54 25.77N 023 23 13.94E	PCN 85 / R / C / W / T	24 - 55 53 49.19N 023 22 57.59E	PCN 60 / R / B / W / T
7 - 55 54 21.74N 023 23 18.72E	PCN 85 / R / C / W / T	25 - 55 53 50.67N 023 22 55.81E	PCN 60 / R / B / W / T
8 - 55 54 27.90N 023 24 32.30E	PCN 32 / R / B / X / T	26 - 55 53 51.04N 023 22 55.37E	PCN 60 / R / B / W / T
9 - 55 53 38.99N 023 23 15.43E	PCN 32 / R / C / W / T	27 - 55 53 52.16N 023 22 54.04E	PCN 60 / R / B / W / T
10 - 55 53 38.99N 023 23 14.89E	PCN 32 / R / C / W / T	28 - 55 53 53.27N 023 22 52.71E	PCN 60 / R / B / W / T
11 - 55 53 39.44N 023 23 14.34E	PCN 32 / R / C / W / T	29 - 55 53 53.65N 023 22 52.26E	PCN 60 / R / B / W / T
12 - 55 53 39.90N 023 23 13.80E	PCN 32 / R / C / W / T		
13 - 55 53 40.35N 023 23 13.25E	PCN 32 / R / C / W / T		
14 - 55 53 40.81N 023 23 12.71E	PCN 32 / R / C / W / T		
15 - 55 53 41.27N 023 23 12.16E	PCN 32 / R / C / W / T		
16 - 55 53 41.72N 023 23 11.62E	PCN 32 / R / C / W / T		
17 - 55 53 42.18N 023 23 11.03E	PCN 32 / R / C / W / T		
18 - 55 53 42.63N 023 23 10.53E	PCN 32 / R / C / W / T		

TAXIWAYS	WIDTH	SURFACE	STRENGTH
A,B	21m	concrete	PCN 85 / R / C / W / T
G,H	24m	asphalt - concrete	PCN 65 / R / B / X / U
I	14m	asphalt - concrete	PCN 85 / R / B / X / U
J	22m	asphalt - concrete	PCN 65 / R / B / X / U
K	12m	asphalt - concrete	PCN 85 / R / B / X / U
F,L,M	23m	asphalt - concrete	PCN 32 / R / B / X / U
N,O	23m	asphalt - concrete	PCN 50 / F / A / W / T
P	12m	asphalt - concrete	PCN 42 / F / A / W / T


Note:

- Taxiing to and from stands
- After landing
- Before take-off
- Stands No 4, 8 ARM - Disarm Pad
- MA 2 - start up or test of engines is prohibited. ACFT on stands 1, 2, 3 must not start up engines until the ACFT is placed at a designation start up position on MA 1 or TWY G. ACFT shall obtain push back(towing)/start up instruction from TWR prior start up.
- F.K.L.M - military TWYs
- Holding position markings at the all TWYs except TWYs F and K.

Changes: strength of taxiways N,O,P and aircraft stands No. 9-19, 20-29.

VISUAL APPROACH CHART

ŠIAULIAI / INTL / CIV / MIL



AD ELEV: 443'
ARP: 55 53 38N 023 23 42E

ŠIAULIAI TOWER: 120.400
Scale 1:300 000

ATIS 120.750
Datum : WGS-84

FIS : ŠIAULIAI INFORMATION 124.450
ELEV IN FT, BRG, TRACK ARE MAG



VFR holding



Entry and exit point for VFR traffic



Recommended arrival routes for visual flight path compulsory with radio communication requirement



Recommended departure routes for visual flight path compulsory with radio communication requirement

PAPI(MEHT)

RWY 14L: Left 3.0° (70 FT)
RWY 32R: Left 3.0° (65 FT)

Changes: EY P23 added.